


THERMOBILE®

COOLMOBILE510




SPARE PART LIST



Part 1


POSITION	DESCRIPTION	REFERENCE
1	Frontal cover RAL9006 BUCC.	ACS07.461
2	Alluminum supply grille	ACS07.462
3	Command panel support	ACS07.463
4	Thermostat	ACS07.377
5	Fan speed selector	ACS07.010
6	Command panel label	ACS07.464
7	Command panel protection RAL9006 BUCC.	ACS07.465
8	Display PCB	ACS01.551
9	Knobs	ACS01.021
10	Switch I - 0 - II	ACS07.375
11	Red led Alarm	ACS07.032
12	Green led power	ACS07.031



Part 2


POSITION	DESCRIPTION	COD. ACS
1	Electrical vane	ACS07.304
2	Electric transformer	ACS07.324
3	Control PCB	ACS07.466
4	Contactor	ACS07.006
5	Phase control relay	ACS02.001
6	General Switch	ACS02.217
7	Wiring connection of the display	ACS05.146
8	Grey temperature probe	ACS05.149

THERMOBILE®



Part 3


POSITION	DESCRIPTION	COD. ACS
1	Evaporator coil with refrigerant distributor	ACS07.326
2	Plenum fan	ACS07.478
3	Defrost thermostat support	ACS07.327
4	Defrost thermostat	ACS07.011
5	Inox tray	ACS07.306
6	Handle	ACS07.132
7	Compressor crankcase heater	ACS07.479
8	Compressor kit R410A	ACS07.328
9	Liquid separator	ACS02.213
10	Low pressure switch	ACS02.043
11	Refrigerant filter R407C - R410A	ACS02.013
12	Thermostatic valve R410A	ACS07.319
13	Water filter 1"	ACS07.330
14	Plate condenser R410A	ACS07.329
15	Water connector Male ¾	ACS07.480
16	Connector for condensed water drainage	ACS07.007
17	High pressure switch	ACS07.157
18 - 20 - 21	Condensed water pump complete	ACS07.014
19	Multimax socket with invert phase	ACS07.448
22	Pump support	ACS07.167
23	Flying socket connector IP68	ACS07.045
24 - 27	Reservoir bracket kit	ACS07.307
25	Circulating pump	ACS07.331
26	Water reservoir	ACS07.034
27 - 24	Reservoir bracket kit	ACS07.307
28	Rear panel connector holder RAL9006 BUCC.	ACS07.481
29	L-shaped fitting	ACS07.482
30	Fan	ACS07.053
31	Circulating pump capacitor 16 µF	ACS07.301
32	Substitution pipe kit for peristaltic pump	ACS07.444



Part 4


POSITION	DESCRIPTION	COD. ACS
1	Rear electric panel metal cover RAL9006 BUCC.	ACS07.467
2	Rear metal cover of motorfan vane RAL9006 BUCC.	ACS07.468
3	Rear metal cover of compressor vane RAL9006 BUCC.	ACS07.469
4	Left side panel RAL9006 BUCC.	ACS07.470
5	Eyebolt support	ACS07.320
6	Eyebolt	
7	Handle reinforcement	ACS07.471
8	Omega bottom	ACS07.335
9	Bottom RAL9006 BUCC.	ACS07.472
10	Pivoting wheel Ø80	ACS07.015
11	Pivoting wheel with brake Ø80	ACS07.084
12	Front metal cover of compressor vane RAL9006 BUCC.	ACS07.473
13	Front suction grid RAL9006 BUCC.	ACS07.474
14	Air filter	ACS07.340
15	Plate condenser support	ACS07.334
16	leg hold up	ACS07.338
17	First floor horizontal panel RAL9006 BUCC.	ACS07.475
18	Right side panel RAL9006 BUCC.	ACS07.476
19	Handle reinforcement 2	ACS07.477

THERMOBILE®



Part 5

POSITION #	DESCRIPTION	COD. ACS
1	Fan Ø500mm	ACS07.566
2	Electrical box 100x100x50mm IP56	ACS07.483
3	Flying socket connector IP68	ACS07.046
4	Omega for protection pipe RAL9006 BUCC.	ACS07.484
5	Handle	ACS07.132
6	Lateral panel RAL9006 BUCC.	ACS07.485
7	Spring loaded split pin	ACS01.613
8	Omega Wheels RAL9006 BUCC.	ACS07.486
9	Frontal panel RAL9006 BUCC.	ACS07.487
10	Pivoting wheel with brake Ø80	ACS07.015
11	Pivoting wheel Ø80	ACS07.084
12	Protection pipe	ACS07.488
13	Plastic spacer	ACS01.111
14	Rear panel RAL9006 BUCC.	ACS07.489
15	Water cooler	ACS07.490
16	Support handle	ACS07.361
17	Connection reinforcement	ACS07.491
18	Connector for condensed water drainage	ACS07.007
19	Pivoting connector 90° ¾	ACS07.492
20	Water connector Female ¾	ACS07.493
21	External connections reinforcement	ACS07.494



Part 6

POSITION	DESCRIPTION	COD. ACS
1	Package for external unit	ACS07.495
2	Package for internal unit	ACS07.496